


SETTING NIGHT VISION

Guardzilla features infrared LED lights that provide clear images in low light. The LED lights automatically engage in low light conditions. A clicking sound may be heard during this process. Night vision images are black and white. The night vision feature can be: 1) set to come on automatically in low light; 2) deactivated; or 3) Set to always be on regardless of light conditions. To set the night vision modes:

- 1 Press the **cog** icon below the monitor screen.



- 2 Press the **AUTO** button to have the night vision automatically engage in low light conditions. It will turn black. Press **OFF** to deactivate the function. Press **ON** to have the feature always on.

