

ARMING & DISARMING YOUR GUARDZILLA

Arming your Guardzilla is simple and quick. When you open your app you will see the last view of your camera. Follow these instructions to arm your camera:

- 1** To arm your camera press the green unlocked icon in lower left hand corner of the monitor screen. It will instantly turn red and change to a red, locked icon. The device is now armed and will send notifications to your phone if motion is detected. The 100dB siren will also blare if it was set to **On** in the **Siren Settings** area.
- 2** To disarm your camera, press the red lock icon. It will turn green and the unlocked icon will appear.

