

FACTORY RE-SETTING AND POWER CYCLING YOUR GUARDZILLA CAMERA

This guide describes how to:

- 1) Factory reset your camera; and
- 2) Power cycle your camera.

Power cycling your camera will retain all your settings. It's a good first step if you are experiencing issues with your camera. A **factory reset** of your camera will remove all of your camera's settings and will require you to set up your camera all over again.

FACTORY RE-SETTING YOUR CAMERA


- 1 Make sure that your camera is plugged in.
- 2 Locate the RESET button on the back of your camera.



- 3 Press the RESET button and hold it down. Wait a few seconds for the LED light on the top of the camera to blink red and blue, then release the button. Your camera will now go through the factory reset process. When it finishes re-setting the LED will start blinking green. The camera can now be added back onto your network (see Step 4 below), if desired.

4 To add your camera back onto your new network follow these steps:

STEP 1. On the upper right hand corner of your Guardzilla app's home screen press the blue plus (+) sign.



STEP 2. A carousel of product images will appear. Swipe your finger on the product images until the 180° Indoor All-In-One Video Camera image and title appears, then select **Next** and follow the directions for adding a camera back to your system. See “Adding a Camera” in the Customer Support area of the Guardzilla.com website for detailed directions.

POWER CYCLING YOUR CAMERA

To re-start/power cycle your Guardzilla 180 Indoor camera unplug your camera, then plug it back in. Wait for the camera to re-start, then resume normal operations.